


HOW TO DOWNLOAD VEHICLE UNIT DATA



Before you can download Vehicle Unit data, you must first ensure that the vehicle ignition is on and that a company card is inserted. If you are unsure how to insert a card, please watch our training video on how to insert a driver card.



Once you have a company card inserted, remove the printer cassette by pushing in the top of the flap, taking hold of the bottom edge and pulling out the cassette.



Attach your download equipment to the tachograph via the six-pin connector.



Follow the instructions on your equipment to download data from the tachograph.



Once your data has successfully downloaded, you will see a message saying 'download complete'.



Then, simply remove the download equipment and replace the cassette.